

GPS TRACKING TO CAPTURE CRIMINALS AND RECOVER STOLEN ASSETS

Each **Phone Tracker** is a GPS-based tracking device that protects phones during a crime by helping law enforcement track and apprehend criminals, recover stolen phones and deter future crime.

These Instructions Apply to Phone Tracker Model 16

NORMAL OPERATING PROCEDURES

Never remove the two tamper-proof seals on the back of the Phone Tracker. A fee will be charged if the Tracker must be returned to 3Si for repackaging.

- Always keep Phone Tracker where you have similar smartphone inventory in your store.
- Phone Tracker is fully automatic and activates after sensing ten (10) seconds of continuous motion and leaving the Safezone (both must occur). Once activated, it automatically and silently alerts 3Si and your loss prevention department.
- Keep the included yellow transport plate in a different location from where Phone Tracker is installed and somewhere store staff can easily locate it. The transport plate is not needed for day to day use.
- A Phone Tracker should not trigger within the Safezone, however, if for some reason it accidentally activates, leave it stationary for three (3) minutes to reset.

DOs & DON'Ts

- **Do** include Phone Tracker with other store inventory taken during a crime.
- **Do** charge Phone Tracker quarterly using the inductive charging pad.
- **Don't** discuss your store's security practices outside of work.
- **Don't** remove the 2 tamper-proof seals located on the back of the Phone Tracker.

IMPORTANT

At no time should the two (2) tamper-proof seals located on the back of the box be removed from the Phone Tracker. There will be a charge incurred if the Tracker needs to be returned to 3Si for repackaging.

Phone Tracker Model 16



Tracker on Yellow Transport Plate



CHARGING INSTRUCTIONS

The tracker must be charged at least every three (3) months, after being taken during a robbery, or when directed by your Loss Prevention Department. An inductive charging pad, USB cable and power supply is available with the Tracker for charging.

CHARGING SEQUENCE

1. Locate the Phone Tracker and take to an area for charging.
2. Assemble the charging pad, cable and power supply and plug into a wall outlet. A light on the pad indicates power is being supplied to the pad.
3. Align the top phone label on the back of the Tracker with the center of the inductive charge pad.
4. Slowly slide the Tracker on the pad until you hear three chirps to indicate that it is correctly aligned on the pad. If you do not receive the three chirps or if the Tracker continues to chirp, gently slide Phone Tracker around on the charging pad to realign until you receive the chirps.
5. Charge Tracker for at least two (2) hours.
6. After charging, place Phone Tracker back to where it was installed so it is in place if a crime occurs.

CHARGING TIPS

- Charge Tracker for at least two (2) hours. Loss Prevention will receive a “Charge-Complete” alert when it is fully charged.
- **DO NOT LEAVE THE TRACKER ON THE CHARGER OVERNIGHT** because it will not be with other inventory and ready to track criminals if a crime occurs.




VESSEL NUMBER

Phone Tracker has an assigned Vessel Number. The Vessel Number is displayed on the back of the Tracker, circled to the right.

This provides a unique identifier from the real smart phone inventory while remaining covert and resembling inventory phones.

NOTE: xxxx in the vessel number represents a random set of numbers.

Phone Tracker 12 (Vessel Number Location)



Possible Vessel #'s for Phone Tracker 12:


812-xxxxx-A

82P-xxxxx-A

VC8SP-xxxxx-A

VC82P-xxxxx-A

Phone Tracker 13 (Vessel Number Location)



Possible Vessel #'s for Phone Tracker 13:

813-xxxxx-A

VC83P-xxxxx-A

Phone Tracker 14 (Vessel Number Location)



Possible Vessel #'s for Phone Tracker 14:

S14xxxxxWL

P14xxxxxDF

C14xxxxxY2

Phone Tracker 15 (Vessel Number Location)



Possible Vessel #'s for Phone Tracker 15:

S15xxxxxWL

P15xxxxxDF

C15-xxxxx-Y2

Phone Tracker 16 (Vessel Number Location)



Possible Vessel #'s for Phone Tracker 16:

S16xxxxxVZ

P16xxxxxVZ

C16-xxxxx-Y2

Any Questions? Please Call 3Si Customer Service at 800.523.1430 Toll-free 24/7/365

FOR YOUR PROTECTION: The information and recommendations in this publication are, to the best of our knowledge, reliable. Recommended suggestions are only the opinion of 3Si Security Systems. **3Si MAKES NO WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING THOSE OF MERCHANTABILITY AND FITNESS FOR PURPOSE**, other than those express warranties set forth in the proposal for the Phone Tracker System. Statements herein, therefore, should not be construed as representations or warranties. Statements contained herein are not to be construed as recommending the infringement of any patent and no liability for infringement arising out of any such use is assumed. This document is proprietary and confidential. No part of this document may be disclosed in any manner without prior written consent of 3Si Security Systems.

© 2025 3Si. All Rights Reserved.

